

# **SST BILLET STYLE GRILLE INSERT**

2004+ NISSAN TITAN  
2004+ NISSAN ARMADA

Model #785069



1. Grille must be temporarily removed for this application. Open the vehicles hood to allow access to the top of the grille. There are (6) square ¼ turn fasteners, (three on top and three on bottom). Using a standard screwdriver, turn the fasteners Counter-clockwise to release. There are also 2 clips on each side of the grille that will have to be released in order for grille to be removed. Lay grill face down on clean surface. Remove the 2 side deflectors on back side of grille in order to gain access for the bolts.
  2. Install the billet grille inserts as follows:
    - 2.1. One at a time, position each grille insert into the openings of the vehicle grille.
    - 2.2. While holding the grille insert in place, install a foam covered retainer plate over each stud (foam side forward), with washer and attach nylock. Do not over tighten.
    - 2.3. Repeat steps 2.1 and 2.2 for all sections.
- NOTE: ON THE LOWER SECTION, THE BLADES WILL GO ON TOP OF THE HORIZANTAL PLASTIC SUPPORT.**
3. Replace the (2) air deflectors onto the backside of the grille. Make sure that the carriage bolts clear the deflectors. Remove the (6) ¼ turn fasteners from the truck and attach to the back of the grille. Place grille in position and snap into place. (6) ¼ turn fasteners and (4) outboard side snaps must all be attached.

## **SERVICE PARTS LIST**

ITEM NO.	QTY	DESCRIPTION
1	1	Billet grille insert, center
2	1	Billet grille insert, right hand
3	1	Billet grille insert, left hand
4	1	Billet grille insert, lower section
5	10	Retainer plate
6	10	¼" washer
7	10	6mm nylock

SERVICE PARTS LIST

MODEL NO. - 785069

